



HydroPoint Data Systems, Inc.  
support@hydropoint.com  
800-362-8774  
www.hydropoint.com

# WeatherTRAK<sup>®</sup>

## Cloud Update Key

### WTUPD-KEY INSTALLATION GUIDE



Read the entire installation  
guide before installing.



# IMPORTANT

Read the entire installation guide before installing.

- Before you install the **Cloud Update Key**, please make sure your controller is an **ET Pro3**, **ET Pro3 2-Wire**, or **LC** and it does not currently have a USB key in the slot on the back of the front panel.
- The **Cloud Update Key** is for use on one controller and must remain installed to maintain functionality.
- After installing the **Cloud Update Key**, the controller will automatically update to the latest firmware version.
- As new firmware versions are released, the controller can now update automatically or on-demand.

---

**Note:** If the "Update Key Installed" message does not appear or other issues are encountered, call customer support at 1-800-362-8774.

1. With the power still on, swing open or unscrew and remove the front panel.
2. Insert the **Cloud Update Key** as pictured, LED on key should briefly light up. If it doesn't, remove and reinsert.
3. Place "Do Not Remove" sticker and close or reattach the front panel.
4. Using the Help and arrow buttons, navigate to "Help : 17-03".
5. Press "\*" button to reset the controller, wait ~10 seconds. The controller will beep as it updates the firmware (~20 seconds).
6. Once updated, the controller will initialize; look for the "Update Key Installed" message in the bottom left corner of the display.
7. Once controller is up and running, place the "Cloud Updates Enabled" sticker in the bottom of the control panel.

